




QUICK START GUIDE



INFLATING YOUR BOARD

- 1 Before connecting the hose, make sure the inflation valve is in the **CLOSED/UP** position.
- 2 Connect the hose and set the pump to **SETTING 1**.
- 3 Begin inflating. (The pressure gauge will not read until the board reaches 7 PSI.)
- 4 Midway through inflation, when pumping becomes more difficult, unscrew the plug from top cap of pump body.
- 5 When nearing full inflation, set the pump to **SETTING 3** and fill to max PSI.



DEFLATING YOUR BOARD

- 1 Make sure the air valve is dry.
- 2 Press firmly on the air valve top for 2 seconds, then twist it to lock into the **OPEN/DOWN** position.
- 3 Allow air to escape for a few minutes. **(Be prepared for a loud rush of air!)**



15 PSI = APPROX. 250 PUMPS (VARIES FOR EACH PERSON)



VALVE WRENCH IS FOR REPAIR USE ONLY – DO NOT USE TO DEFLATE



INSTALLING YOUR FINS

- 1 Lift the lock on the fin box to the **OPEN/UP** position.
- 2 Insert the front of the fin into the notched section of the fin box. Rock the fin back and down until it's in place, then press the fin lock lever down to secure.
- 3 Make sure the fin is securely attached before paddle boarding.

Please contact us with any questions!

1-866-985-8367

www.irockersup.com

